

Adjustable Fillet Weld Gauge with unequal leg measurement feature



G.A.L. Adjustable Fillet Weld Gauge is easy to use.



To measure fillet welds place irregular curve edge flush to horizontal toe of weld so the straight edge is in line with the horizontal member.



To measure weld throat thickness place the 45° angle end flush to the horizontal and vertical members. Loosen the thumb screw and slide the pointer until it touches the face of the weld.